

Reduces the amount of plastic used!



Q-Lite is already pre-stretched, so needs less tension and is easy to use!

Follow the easy steps below for best use

1.

Unwind approximately 1 metre off the roll and tie to the foot of the pallet.

2.

Wrap around the base of the load and the pallet three to four times to secure the two together.

3.

At each corner, stretch the film slightly to allow the correct amount of tension.

4.

Continue to wrap around the load in an upward spiral motion and allowing a 30 – 50% overlap.

5.

To finish, tear off the roll and secure the loose end to the pallet by applying light pressure with the palm of your hand.

KEY POINTERS:

- ENSURE THE WRAP HAS BEEN SECURED TO THE PALLET
- HAVE I GIVEN ENOUGH TENSION TO THE FILM?
- DOES THE FILM “FLICK BACK” TO THE PALLET ONCE WRAPPED?

Castle Tapes & Industrial Solutions



Technical tapes, adhesives, packaging and Workwear/PPE supplies

Web www.castletis.co.uk email web@castletis.co.uk

Tel. (Walsall) 01922 626 664 Tel. (Nottingham) 0115 939 6061